

PRINTMAKER 35/67 ENLARGER REPLACEMENT PARTS LIST

NOTE: All chassis parts are common with the Printmaker Dichro 35.

REF. NO.	DESCRIPTION	PART NO.	REF. NO.	DESCRIPTION	PART NO.
1	Negative Stage	10-42019-22	41	Hex Head Tap Screw #10-32x3/4	538-23-24-07
2	Focusing Shaft	10-42024	42	Shoulder Screw	540-30-52
3	Focusing Shaft Spring	10-42027	43	Pad-Baseboard	10-42018
4	Lens Board Spring	10-42032	44	Tee Nut 1/4 - 20	546-40-15
5	Lens Board Retainer	10-42033	45	Hex Slot Mach. Screw 1/4-20x3/4	527-24-41-06
6	Spline	10-42037	46	Bow Washer 17/64x9/16x1/16 High	549-20-19
7	Bearing Pad	10-42041	47	Wire Connector	600-25-22
8	Bellows	10-42045	48	Wing Nut 10-32	546-20-13
9	Bellows Retaining Angle	10-42052	49	Enlarger Lamp 120v	cat. #8101
10	Lens Stage	10-42182	49A	Enlarger Lamp 240v	cat. #8114
11	Carriage Lock Stud	10-45934	50	Lamp Socket	625-82-07
12	Carriage Upper Bearing	10-45937	51	Speed Nut 6-32 "U" Type	555-05-03
13	Carriage Lower Bearing	10-45938	52	Pan Head Tap Screw 6Bx5/16	538-19-10-12
14	Carriage Locking Spacer	10-45939	53	Pan Head Mach. Screw 6-32x5/16	519-10-02-01
15	Carriage Lock Knob	10-45932	54	Hex Lock Nut 6-32	546-55-04
16	Elevator	10-45964	55	Pan Head Mach. Screw 10-32x3/8	524-12-02-01
17	Bottom Filter Holder	10-42103	56	Lockwasher #10	549-47-08
18	Column	10-45955	57	Hex Locknut 10-32	546-55-08
19	Carriage Spring	10-45931	58	Red Safety Filter	cat. #8040
20	Carriage Spring Clamp	10-45940	59	Screw, Mach. 8-32 x 1/4	521-40-02-01
21	Carriage Spring Housing	10-45936	60	Nut, Lock #8-32	546-57-08
22	Lamphouse Left Side	10-42091-01	61	"U" Type Clip	555-42-23
23	Lamphouse Right Side	10-42091-02	62	Pan Head Lock Screw 6-32x3/8	540-60-73
24	Lamphouse Wraparound	10-42092-04	63	Hex Nut 6-32	545-19-20-01
25	Front Heat Shield	10-42093	64	Pan Head Tap Screw 8BTx1/4	538-21-08-29
26	Rear Heat Shield	10-42153	65	Pan Head Tap Screw 8BTx5/16	538-21-10-08
27	Lamp Socket Bracket	10-42155	66	Pan Head Tap Screw 6BTx3/8	538-19-12-44
28	Power Cord 120v	10-42164	67	Pan Head Tap Screw 4Bx3/16	538-13-06-16
28A	Power Cord 240v	10-42169	68	Pan Head Tap Screw 4Bx1/4	538-13-08-32
30	Lamphouse Door	10-50726	69	Pan Head Mach. Screw 6-32x1/8	519-04-02-01
31	Focusing Bar	10-45979	70	Hex Head Mach. Screw 6-32x5/16	519-10-40-01
32	Carriage	10-45951	71	Plain Washer #6	548-18-07
33	Enlarger Base Board	10-45960	72	Hex Head Lock Screw 10-32x3/8	540-60-20
34	Knob, Recess	568-40-10	73	Plain Washer #10	548-24-04
35	Lens Board (Accessory)	cat #6723	74	Hex Nut 8-32	545-21-20-01
36	Safe Filter Holder	10-42040	75	Lock Washer #8	549-45-08
37	Elevating Arm	10-45923	76	Fan Head Mach. Screw 6-32x1-3/4	519-56-02-02
38	Focusing Knob	10-45933	77	Extension Spring	562-70-64
39	4" Condenser Assy	10-42098	78	Power Cord Bushing	600-82-30
39a	2 1/4" condenser assembly (1 ea)-Printmaker 35"	10-45907	79	Pan Head Mach. Screw 10-32x3/8	524-12-02-01
40	Filter Holder Assy	10-47824	80	2-1/4" Condenser (not shown)	10-45907

* Same placement in light source as lower 4" condenser lens (#39).