

23C III-XL PARTS LIST

REF. NO.	DESCRIPTION	PART/CAT. NO.	REF. NO.	DESCRIPTION	PART/CAT. NO.	REF. NO.	DESCRIPTION	PART/CAT. NO.
1	Lamp Cap Assembly	10-43755-15	46	Knob	568-20-31	94	Screw, Tapp 6Bx ³ / ₁₆ Lg.	538-19-06-08
1A	Lamp Cap Assembly (240V)	10-43755-20	47	Indicator	10-07628	95	Spring, Wire .2180D	562-70-14
2	Lamp, PH140	8101	48	Lens Stage	10-44052	96	Screw, Machine 10-32x ³ / ₁₆ Lg.	524-06-02-01
2A	Lamp, PH1400 (240V)	8114	49	Screw, Machine 6-32x ⁵ / ₁₆ Lg.	521-10-02-01	97	Screw, Machine 10-32x ³ / ₁₆ Lg.	524-12-02-01
3	Knob	568-20-05	50	Spring	10-04543	98	Lockwasher, #10	549-40-15
4	Lamp Socket	625-82-07	51	Lens Extension	Accessory	99	Shaft	10-44051
5	Strain Relief	600-82-30	52	Rear Retainer	10-04542	100	Screw, #8-32x ¹ / ₂ Lg.	521-16-02-05
5A	Strain Relief (240V)	600-82-25	53	Screw, Tapp 4BTx ³ / ₈ Lg.	538-13-12-31	101	Guard	10-07680-03
6	Wire Nut	600-25-22	54	Forward Retainer	10-44056	102	Bow Washer, ²⁹ / ₆₄ IDx ³ / ₁₆ ODx ³ / ₃₂ H	549-20-27
7	Cord Set	10-43748	55	Lensboard	Accessory	103	Washer, .377IDx.792ODx.031	548-46-16
7A	Cord Set (240V)	10-43743	56	Filter Holder Assembly	10-43758	104	Washer, ²⁹ / ₆₄ IDx ³ / ₁₆ ODx ¹ / ₁₆ (2 pcs.)	548-48-13
8	Screw, Machine ¹ / ₄ -20x ³ / ₈ Lg.	527-12-02-01	57	Filter, Safety	8040	105	Shoulder Screw, 10-32x ³ / ₁₆ Lg	540-30-28
9	Indicator, Negative Size	10-07684	58	Speed Nut, U-Type 6-32 Tinn	555-05-31	106	Roller	10-07606
10	Cover	10-07686	59	Screw, Mach 6-32x ³ / ₄	519-24-02-01	107	Washer, 10x ¹ / ₂ OD	548-24-09
11	Bushing, Snap .562 Mount	570-50-33	60	Tension Spring	10-07650	108	Nut, Lock Hex 10-32	546-57-13
12	Lamp Housing Assembly	10-54642	61	Lower Housing	10-07649-03	109	Cross Carriage	10-07626
13	Shaft	10-07690	62	Shaft	10-07652	110	Washer, 10x ¹ / ₂ OD	548-24-09
14	Friction Wheel	10-07651	63	Friction Wheel	10-07651	111	Lockwasher #10	549-40-15
15	Set Screw, Headless 8-32x ³ / ₁₆	540-20-60	64	Knob	568-05-07	112	Screw, 10-24x ³ / ₈ Lg.	523-12-60-02
16	Knob	568-05-07	65	Screw, Mach 6-32x ¹ / ₂ Lg.	519-16-02-01	113	Retaining Ring, E Type	555-26-14
17	Screw, Machine 6-32x ¹ / ₂ Lg.	519-16-02-01	66	Set Screw, Headless 8-32x ³ / ₁₆	540-20-60	114	Shaft, Spring Drum	10-43722
18	Tension Spring	10-07650	67	Vertical Stop	10-07645	115	Constant Force Spring Assembly	10-43718
19	Screw, Machine 6-32x ³ / ₄ Lg.	519-24-02-01	68	Nut, Hex ¹ / ₄ -20	545-27-20-01	116	Bracket, Spring Drum Mounting	10-43723
20	Speed Nut, U-Type 6-32 Tinn	555-05-31	69	Screw, Machine ¹ / ₄ -20x ¹ / ₂ Lg.	527-48-40-45	117	Gusset, Lower Frame (R. H.)	10-43726-02
21	Guide, Rod	10-44057-01	70	Cover	10-54624	118	Gusset, Upper Frame	10-07746
22	Heat Absorber Glass (Accessory)	8042	71	Knob	568-40-06	119	Screw, Tapp 8Bx ³ / ₈ Lg.	538-21-12-06
23	Filter Holder	10-07685	72	Stage Opening Lever	10-07630	120	Frame Assembly	10-43717
24	Condenser Assembly	10-07662	73	Cam	7000	121	Screw, Machine ¹ / ₄ -20x ⁷ / ₈ Lg.	527-28-32-01
25	Condenser, Upper	680-16-45	74	Stud	10-04613-01	122	Screw, Tapp 10Bx ⁵ / ₁₆ Lg.	538-23-10-02
26	Spacer	10-07664	75	Set Screw, Headless 6-32x ³ / ₁₆	540-20-13	123	Gusset, Lower Frame (L. H.)	10-43726-01
27	Condenser, Lower	680-22-07	76	Set Screw, Headless 6-32x ³ / ₈	540-20-17	124	Baseboard	10-43728-02
28	Pad	10-07665	77	Set Screw, Headless ¹ / ₄ -20x ⁵ / ₁₆	540-22-52	125	Pad, Baseboard	10-42018
29	Screw, Tapp 4Bx ³ / ₈ Lg.	538-13-12-30	78	Knob	10-59628	126	Tee Nut, Propeller ¹ / ₄ -20	546-40-15
30	Condenser Housing	10-07663	79	Bracket	568-99-01	127	Upper Housing	10-54635
31	Speed Nut, Flat 4Z Tinn	555-01-03	80	Set Screw #8-32x ³ / ₁₆	540-22-79	128	Spacer	557-21-53
32	Light Seal	10-07661	81	Bar, Clamping	10-53790-01	129	Screw ⁵ / ₁₆ -18x ² / ₁₂	527-80-40-02
33	Upper Bellows Assembly	10-07659	82	Bar, Clamping	10-53790-02	130	Cover	10-54645-02
34	Bow Washer, ¹ / ₄ IDx ¹ / ₂ ODx ³ / ₃₂ H	549-20-17	83	Gear	Gear Replacement Kit 7002	131	Block	10-54629
35	Shoulder Screw, 10-24x.406 Lg.	538-19-08-37	84	Elevating Handle Assembly	7003	132	Screw #8-32F	538-21-16-23
36	Screw, Tapp 6Bx ¹ / ₄ Lg.	562-70-09	85	Shoulder Screw, 10-24x.380 Lg.	540-30-12	133	Washer #8	548-22-02
37	Spring, Wire Ext. .1730D	555-26-14	86	Bow Washer ¹⁷ / ₆₄ IDx ⁹ / ₁₆ ODx ¹ / ₁₆ H	549-20-18	134	Eccentric Nut	546-80-10
38	Retaining Ring, E Type ³ / ₈ Shaft	10-07679	87	Latch	10-07612	135	Nut #8-32	546-55-06
39	Negative Carrier	Accessory	88	Washer, 10x ¹ / ₂ OD	548-24-09	136	Bearing	560-50-40
40	Lower Negative Stage	10-07642	89	Stop	10-07609	137	Alignment Screw	540-80-15
41	Lower Bellows	10-07653	90	Lock Nut, Hex 10-32	546-57-13	138	Screw, #8-32x ³ / ₁₆ Lg.	521-10-02-01
42	Tilt Plate	10-07627	91	Washer, 10x ³ / ₄ OD	548-24-29	139	Baffle-Light	10-07672-02
43	Bow Washer, ²¹ / ₆₄ IDx ³ / ₁₆ ODx ¹ / ₁₆ H	549-20-25	92	Lockwasher, #10	549-40-15	140	Cap	570-42-71
44	Shoulder Screw, ¹ / ₄ -20x.642 Lg.	540-30-57	93			141	Clamp Screw	10-54638