

23C III-XL V.C. HEAD REPLACEMENT PARTS LIST

REF.	NO.	DESCRIPTION	PART/CAT. NO.			
	1	Rear Chassis Plate	10-54710	68	Dial Knob	568-01-83
	2	Bottom Aperture Plate	10-54715-01	71	Lamphouse Side (Left)	10-42091-01
	3	Top Aperture Plate	10-54715-02	72	Lamphouse Side (Right)	10-42091-02
	4	Filter-Windows	10-42624	73	Lamphouse Wraparound Assembly	10-54647
	5	Holder-Filter	10-42623	74	Wire Connector	600-14-22
	6	Filter Blade Assembly	10-42622	75	Tap Screw #6Bx6/16 Pan	538-19-10-12
	7	Blade Spacer	10-42658	76	Lamphouse Cushion	10-42124
	8	Blade Guide Spacer	10-42657	77	Mix Chamber	10-42614-20
	9	Blade Follower	10-42667	78	Heat Filter	10-42685
	10	Knob	10-42687	79	Tape (Both Ends)	10-42713
	13	Filter Blade Spring	10-42686	80	Liner (Both Ends)	10-51624-01, -02
	14	Machine Screw 2-56x3/32 Pan	509-03-01-01	81	Liner (Filter Side/Top)	10-42678-01
	15	Machine Screw 2-56x1/8 Flat	509-04-90-01	82	Liner (Side/Top)	10-42678-02
	16	Flat Washer #6x3/8	548-18-07	83	Liner (Both Sides/Bottom)	10-42678-03
	17	Flat Washer #6x1/2	548-18-18	84	Diffuser	10-51626
	18	Locknut 6-32	546-57-07	85	Bottom Plate	10-51625
	19	Wire Clip	555-40-08	86	Tap Screw #4B1/4	538-13-06-32
	20	Sems Screw 6-32	540-60-48	87	Light Trap Frame Cushion	10-42716
	21	Machine Screw 4-40x7/16 Pan	515-14-02-01	88	Corner Cushion	10-42704
	22	Machine Screw 4-40x5/16 Pan	515-10-02-01	89	Bottom Cushion	10-42707
	23	Lockwasher #4	549-47-02	90	Rectifier	635-70-22
	24	Lamp Holder/Bracket	10-46183-91			
	25	Keps Nut 4-40	546-55-04			
	26	Enlarger Lamp 85W/82V	Cat. #6728			
	27	Power Cord	10-46186			
	28	Power Cord Bushing	600-82-28			
	29	Light Trap	10-42672			
	30	Machine Screw 4-40x1/4 Pan	515-08-02-06			
	31	Machine Screw 6-32x1/4 Pan	519-08-02-01			
	32	Front Chassis Plate	10-51622			
	33	Keps Nut 4-40	546-55-02			
	34	Plain Nut 4-40	545-15-20-01			
	35	Machine Screw 4-40x3/8 Fill.	515-12-11-40			
	36	Cam Ass'y.	10-54666			
	37	Cam Shaft	10-54684			
	38	Sems Screw 4-40x1/4 Pan Slot	540-60-27			
	38A	Clip, Holddown	10-42736			
	39	Retaining Ring "E" Type 1/4	555-26-10			
	40	Flat Washer #14x1/2	548-32-07			
	41	Bow Washer 17/64 ID	549-20-34			
	45	Sems Screw 4-40x1/4 Pan	540-60-47			
	46	Bullet Catch 1/4 Dia.	570-10-17			
	47	Tap Screw #4Bx3/8 Pan	538-13-12-30			
	48	WhiteLight Shaft	10-42681			
	49	White Light Actuator Lever	10-42676			
	50	Cap Screw 4-40x1/2 Pan	515-16-53-01			
	51	Light Trap Top Cushion	10-42706			
	52	Shaft Support Bracket	10-42654			
	56	Dial Ass'y.	10-54685			
	57	Sems Screw 2056x1/8 Pan	540-60-55			
	58	Front Cover-Sub-Ass'y.	10-54669			
	59	Speed Nut "U" Type #4B	555-05-23			
	60	White Light Handle	568-32-08			
	61	Light Trap Actuator Cushion	10-42705			
	63	Front Plate	10-54680			
	63A	Bezel	10-42729			
	64	Side Panel	10-42653			
	66	Front Plate Bar	10-42689			
	67	Set Screw 4-40x3/32 Oval	540-20-62			