


**CS-14 (Model #4200) / CLA**  
 (Camera and Lights not included)  
 (Shown for illustration)

**Figure 1**

**CS-Digital/Photo-Video - CS-DPV**  
**(Model #4211) / CLA**  
 (Camera and Lights not included)  
 (Shown for illustration)

**Figure 2**



1. Elevation Lock Knob (CS-14)
2. Camera Platform
3. Camera Lock Knob (Not Shown)
4. Camera Platform Lock Knobs
5. Column
6. Baseboard
7. Positioning Grid
8. Elevation Scale

9. Base Tilt Lock Knob
10. Sliding Light Mount with Lock Knob
11. Horizontal Arm Lock Knobs
12. Light Mounting Stud
13. Carriage Elevation Lock, Model #4211-02 (not shown)
14. Elevating Crank
15. Carriage